## www.reelschematic.com

resistant materials require minimum care.

If used in salt water, be sure to remove the spool and rinse your reel thoroughly in warm fresh water. Then, wipe dry. Do not apply water under pressure, since this simply forces salt water particles into your reel's mechanism. When used in salt water we suggest spraying the metal parts of your reel, after each trip, with a moisture absorbent spray such as WD-40.


Always remove any sand particles from your reel. Should you accidentally drop your reel in sand or gravel, it may be necessary to disassemble and thoroughly clean all parts before further use. The push button spool removal system on your reel makes this job easy. Apply a high-grade lubricant, such as South Bend "Super Reel Oil" (with Teflon), on all of your moving parts (with the exception of the disc drag system). At least once a year, remove the spool and grease the main shaft with South Bend "Super Reel Grease", which is especially formulated for fresh and salt water reels.

## LIMITED WARRANTY

Crystal River will repair or replace any product which proves defective in work-manship or materials within ninety days from the date of original purchase.

This warranty does not cover damage caused by negligence, accident, misuse, alteration of the product, or normal expected wear. Damage that is determined to be of this nature will be repaired at customer's expense.

IMPORTANT-Specify reel model number when ordering parts. Example—Extra spool for Crystal River Royal Coachman Rim Fly Reel CR-2101—specify CR-2101 (reel no.) - 11 (spool part no.)



KEY NO.	DESCRIPTION	XEY	DESCRIPTION	
12345678910112131456789222234	P/BUTTON COVER SCREW PUSH BUTTON COVER PUSH BUTTON SYRING LOCK PLATE COVER SPOOL LOCK PLATE LOCK PLATE SPRING HANDLE RIVET HANDLE RIVET HANDLE RIVET HANDLE WEIGHT(ONLY AXLE II) 'O'- RING SPOOL BUSH(AXLE II - BALL SEARING) AD JUST W/S SILENT CAM RATCHET STOPPER RIVET RATCHET COVER DRAG DISK MAIN SHAFT	25 26 26 27 28 30 31 31 31 31 31 31 41 42 42 43 44 45 44	S/P LOCK PLATE CLICK PAWL S/P CLICK PAWL S/P CLICK PAWL COVER C/PAWL COVER S/C DRAG W/S 'A' DRAG W/S 'A' DRAG W/S 'B' DRAG W/S 'B' DRAG W/S 'B' DRAG W/S 'B' PFAME UNIT FRAME LABEL LINE GUIDE L/GUIDE S/C LINE ROLLER L/GUIDE LABEL STAND SCREW D/KNOB RETAINER DRAG STOPPER D/STOPPER D/STOP	